

Thank you for using Badge Design, we hope we have exceeded expectations and lived up to our reputation. Please find below the instructions of how to apply an iron-on badge to a garment.

APPLYING IRON-ON BADGES

Throughout this process there are several things to avoid to achieve the best possible result:

- Do not use steam
 - Do not remove the plastic backing on the badge: this is actually the glue
 - Do not iron on an uneven surface
 - Do not use a back-and-forth motion with the iron
1. Set iron temperature to max (if it reads digitally, then set it to 175 degrees)
 2. Place the badge in the desired location, with the design on top.
 3. Cover the badge with greaseproof paper, an old cloth, pillow case or similar.
 4. Press the iron directly down for 35 to 45 seconds with a constant level of pressure.
 5. Turn the garment inside-out
 6. Cover the garment with the greaseproof paper, old cloth, pillow case or similar item
 7. Press the iron directly down from the reverse side for 35 to 45 seconds, I.E. you are pressing down on the back of the badge, not the decorated side.
 - a. If it is not possible to complete step 7, then repeat process 4 a second time.
 8. Allow the garment to cool for 5 minutes.





TRI-ACETATE FABRICS

The badge should then be washable, dryable and dry-cleanable.

If the badge then loosens at the edges prior to, or after, a wash then simply re-apply the above instructions; ideally using a different iron, as old irons tend to lose the uniformity of heat across the plate.

Alternatively, use a permanent fabric-glue available from most arts and crafts stores.

Kind Regards,

Badge Design Customer Services